

GoBidet 2003-HIK Hot Water Kit Installation Instructions

1. If your GoBidet 2003C is already hooked up to cold water, be sure to turn the water supply off before adding this hot water kit.
2. On the GoBidet body, you will find a slotted head cap next to the cold water connection.



3. Remove the slotted head cap and discard it.
4. Wrap the threads of the 3/8" chrome nipple in the HIK kit with Teflon tape and insert the nipple into the GoBidet body.



5. Wrap the threads on the newly inserted 3/8" nipple with Teflon tape and attached the new 60" braided steel hose.
6. Shut off the water supply at your hot water source (typically under the sink) and remove the existing hot water line from the connection.
7. Wrap the threads on the enclosed t-valve and attach it to your hot water connection.
8. Reattach the existing hot water line and attach the new 60" braided steel hose that you connected to the GoBidet in step 5.
9. Turn on your water supply lines and check for leaks.

Please visit www.Go-Bidet.com for more information
or call 800-681-0753